

# OPERATING INSTRUCTIONS MANUAL

(Please retain for future reference)

For

## FVNP-200RC INDIRECT FIRED SPACE HEATERS

CERTIFIED FOR USE IN CANADA AND U.S.A.  
As per Standard ANSI Z83.7/CSA 2.14 2000 Gas Fired Construction Heaters / Unattended Type.



Issue date: August 1, 2017



FLAGRO INDUSTRIES LIMITED  
ST. CATHARINES, ONTARIO  
CANADA

**GENERAL HAZARD WARNING:**

**FAILURE TO COMPLY WITH THE PRECAUTIONS AND INSTRUCTIONS PROVIDED WITH THIS HEATER, CAN RESULT IN DEATH, SERIOUS BODILY INJURY AND PROPERTY LOSS OR DAMAGE FROM HAZARDS OF FIRE, EXPLOSION, BURN, ASPHYXIATION, CARBON MONOXIDE POISONING, AND/OR ELECTRICAL SHOCK.**

**ONLY PERSONS WHO CAN UNDERSTAND AND FOLLOW THE INSTRUCTIONS SHOULD USE OR SERVICE THIS HEATER.**

**IF YOU NEED ASSISTANCE OR HEATER INFORMATION SUCH AS AN INSTRUCTIONS MANUAL, LABELS, ETC. CONTACT THE MANUFACTURER.**

**WARNING:**

**FIRE, BURN, INHALATION, AND EXPLOSION HAZARD. KEEP SOLID COMBUSTIBLES, SUCH AS BUILDING MATERIALS, PAPER OR CARDBOARD, A SAFE DISTANCE AWAY FROM THE HEATER AS RECOMMENDED BY THE INSTRUCTIONS. NEVER USE THE HEATER IN SPACES WHICH DO OR MAY CONTAIN VOLATILE OR AIRBORNE COMBUSTIBLES, OR PRODUCTS SUCH AS GASOLINE, SOLVENTS, PAINT THINNER, DUST PARTICLES OR UNKNOWN CHEMICALS.**

**WARNING:**

**NOT FOR HOME OR RECREATIONAL VEHICLE USE.**

**WARNING:**

**INTENDED USE IS PRIMARILY THE TEMPORARY HEATING OF BUILDINGS UNDER CONSTRUCTION, ALTERATION, REPAIR OR EMERGENCIES ONLY.**

**This heater is designed and approved for use as a construction heater under Standard ANSI Z83.7/ CGA 2.14. 2000.**

**We cannot anticipate every use which may be made of our heaters. CHECK WITH YOU LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT APPLICATIONS.**

**Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.**

### **SPECIFICATIONS**

Model .....	FVNP-200RC
Input Range.....	200,000 btuh
Fuel .....	Propane Natural Gas
Manifold Pressure .....	1.45" W.C. Propane 3.44" W.C. NG
Maximum Inlet Pressure .....	13" W.C. Propane 10" W.C. NG
Electrical .....	115V 15 AMP  (6 AMP Draw)
Ignition .....	Direct Spark Ignition
.....	Thermostat Control
Air Circulation .....	2600 cfm
Fuel Consumption .....	9.25 lbs/hr Propane  190 cfh NG
Approved .....	cETLus listed

## INSTALLATION:

The installation of this heater for use with natural gas shall conform with local codes or, in the absence of codes, with the National Fuel Gas Code ANSI Z223.1/NFPA 54 and the Natural Gas and Propane Installation Code, CSA B149.1-00. This heater must be installed by a qualified gas technician, following local codes published by the authority having jurisdiction. All installations performed in the state of Massachusetts must be completed by a qualified plumber and gas fitter of the State of Massachusetts.

The installation of this heater for use with propane tank or cylinder shall conform with Local codes or, in the absence of local codes, with the Standard for the Storage and Handling of Liquefied Petroleum Gases, ANSI/NFPA 58 and the Natural Gas and Propane Installation Code, CSA B149.

This heater must be located at least 10ft (3m) from any propane gas cylinder. This heater shall not be directed toward any propane gas container within 20ft (6m).

### CLEARANCE TO COMBUSTIBLES:

<u>TOP</u>	<u>FRONT</u>	<u>SIDES</u>	<u>REAR</u>	<u>FLUE PIPE</u>
3 ft	10 ft	1 ft	2 ft	3 ft

## ELECTRICAL:

### WARNING

#### Electrical Grounding Instructions

This appliance is equipped with a three-prong (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle.

115v supply must be available. Please note that the heater requires 15 amps for proper operation. Ensure appropriate gauge extension cord is used.

- 12/3 AWG at 50 Feet
- 10/3 AWG at 100 Feet

## CONNECTING THE CYLINDER:

If cylinders are being use, no cylinders smaller than 100lb capacity shall be used. These cylinders must supply a vapour withdrawal only.

1. All cylinder connections must be made using a wrench to tighten the POL fitting.
2. Be sure that the cylinder valve is in the closed position when connection or disconnecting the cylinder.
3. A soap and water solution must be applied to all connections in order to leak check the system.

The gas must be turned off at the propane supply cylinder(s) when the heater is not in use. When the heater is to be stored indoors, the connection between the propane supply cylinder(s) and the heater must be disconnected and the cylinders removed from the heater and stored in accordance with Standard for the Storage and Handling of Liquefied Petroleum Gases, ANSI/NFPA 58 and CSA B149.1, Natural Gas and Propane Installation Code.

**PIPING:** This heater must be installed by a qualified gas technician following local codes published by the authority having jurisdiction. Sizing of supply piping must be determined using the length of pipe run as well as total btuh rating of the appliance(s). Appropriate piping tables must be used to determine size of supply piping dependant on the length of run from source.

<b>PRESSURES:</b>	MAXIMUM INLET PRESSURES:	LP: 13.0 IN. WC.
		NG: 10.0 IN. WC.
	MINIMUM INLET PRESSURES:	LP: 8.0 IN. WC.
		NG: 7.0 IN. WC.

This heater must be supplied by pressures indicated on the approval label. Over pressure may cause controls to fail.

DO NOT supply this unit with more than ½ psig (14.0 in. W.C.)

Note: A second stage regulator must be installed if the supply pressure exceeds ½ psig.

**FUEL:** This heater is a dual fuel unit and operates on propane & natural gas. The manifold pressures are listed on the approval label. You do not need to change any of the burner components; you however need to make sure the fuel selector valve on the manifold is in the proper fuel position.

**IMPORTANT**

**Once the fuel selector valve is in the correct position, A LOCKING MECHANISM IS RECOMMENDED TO BE USED ON THE FUEL VALVE TO PREVENT SOMEONE FROM MOVING THE VALVE TO THE INCORRECT FULE POSTION. SEE LABEL ON HEATER FOR VALVE POSTION. IF THE FUEL VALVE IS IN THE INCORRECT POSITION, POTENTIAL HARM TO PERSONEL AND HEATER CAN OCCUR.**

**HOSES:** All hoses used to connect this heater of fuel supply must be Type 1 approved propane / natural gas hose assemblies

**POWER SUPPLY INDICATOR LIGHT:**

The power supply indicator light will help detect any faulty power supplied to the heater such as; grounding issues, reverse polarity or missing/ poor connections.

**Warning Light Indications**

- Green Light ..... Meets Power Requirements
- Solid Red Light..... Reverse Polarity
- Solid Red & Green Light... Ground Issue



**ATTENTION: IF SOLID RED & GREEN IS INDICATED, MAKE CORRECTIONS TO POWER SUPPLY BEFORE TURNING HEATER ON. FAILURE TO DO SO WILL VOID ANY WARRANTY.**

**FLUE PIPE:**


For outdoor applications the flue pipe connection must terminate with a vertical run at least 2 ft long with a rain cap.

For indoor installations the venting must consist of a minimum 2 ft vertical run to a maximum of 20 ft total vent length. See diagram below for horizontal vent installation.


The vent outlet on the heater is 6" diameter. Certified venting must be used at all times. Vent cap should be installed in situations where downdrafts occur. All venting must correspond with CSA B149 standard or in its absence, local codes.

**FV SERIES CONSTRUCTION HEATER – VENTING REQUIREMENTS**

**1. VERTICAL FLUE TERMINATIONS**



**2. HORIZONTAL FLUE TERMINATIONS**



- A - VENT TERMINATION MUST BE A MINIMUM OF 2FT HIGHER THAN ANY POINT WITHIN 10FT.
- B - MAXIMUM HORIZONTAL RUN IS 30FT.  
NOTE: 90deg ELBOW = 10ft HORIZONTAL VENT ALLOWANCE  
45deg ELBOW = 5ft HORIZONTAL VENT ALLOWANCE
- C - VENT TERMINATION IN HORIZONTAL POSITION MUST BE MINIMUM 4ft FROM ANY COMBUSTABLE SURFACE
- D - EXTERIOR VERTICAL VENT TERMINATION MUST BE A MINIMUM OF 2ft.

NOTE: ALL VENT TERMINATIONS MUST HAVE A RAIN CAP INSTALLED AS PER LOCAL CODE REQUIREMENTS.

**OUTLET DUCTING: (maximum of 150ft to be used)**

Heater duct with a minimum temperature handling of 350 deg F including wire reinforcement to prevent collapsing. Heater is designed for use with 12" (FV-HD12) or 16" (FV-HDG16) diameter ducting equipped with pin lock or cuff & buckle provided on collar for ducting. Ducting should be inspected periodically for tearing and/or wear marks. Ducting should be stored in a dry area when not in use.

**INLET DUCTING:**

Ducting must be used on the return air inlet of heater. The heater is designed for 12" inlet diameter ducting (FV-HD12) and is designed for pin lock or cuff and buckle system

**MAINTENANCE:**

1. **Every construction heater should be inspected before each use, and at least annually by a qualified service person. Incorrect maintenance may result in improper operation of the heater and serious injury could occur.**
2. The hose assemblies shall be visually inspected prior to each use of the heater. If it is evident there is excessive abrasion or wear, or the hose is cut, it must be replaced prior to the heater being put into operation. The replacement hose assembly shall be that specified by the manufacturer.
3. The appliance must be kept clear and free from combustible materials, gasoline and other flammable vapors and liquids.
4. The flow of combustion and ventilation air must not be obstructed. Be sure to check the fan assembly and ensure that the motor and blade are operating properly.
5. Compressed air should be used to keep components free of dust and dirt build up.

Note: Do not use the compressed air inside any piping or regulator components.

6. Fan Limit Switch (Part# FV-407A) should be replaced if the fan motor does not shut off after the heat exchanger has cooled down.



7. High Limit Switches (Part# FV-406 & FV-437) should be checked each season. These limit switches will ensure the burner shuts down if the temperature exceeds 250°F at the outlet.
8. Heat Exchanger should be cleaned if smokey conditions continue even after the air adjustments on the burner are made.

### **START UP INSTRUCTIONS:**

1. Position heater properly on a level surface.
2. Be sure the toggle switch is in the 'OFF" position.
3. Connect the fuel supplier to heater (leak test all connections) Refer to chart #1 for hose sizing.
4. **Verify the fuel valve on the heater is in the correct fuel position and the valve has a locking mechanism.**
5. Ensure burner "air gate" is properly set at 3.5
6. Ensure electrical cord is grounded & plugged into a 120V 15 amp outlet. Verify cord size (12/3AWG at 50 ft & 10/3AWG at 100ft).
7. The power indicator light on the control box will engage, if green light illuminates, you have proper power supply. If not, refer to sticker on heater to verify warning problem. Correct power supply problem before operating heater.
8. Move toggle switch to "MANUAL" position for manual control.
9. Move toggle switch to "THERMOSTAT" position for thermostat control. Plug in thermostat.
10. Once the burner has started, you will need to verify and set manifold pressure. See rating plate for manifold pressure
11. Use a manometer to verify manifold pressure is being achieved. If needed, adjust manifold pressure by adjusting the set screw on the RV52 regulator. (small grey appliance regulator on the manifold, rated at ½ PSI)

#### **Please Note:**

1. If using Thermostat on unit, unit must be started in Thermostat position.
2. When changing between manual and thermostat operation, the heater must be left in the "OFF" position for 30 seconds to prevent the burner from locking out.
3. When using a generator for electrical supply, make sure the generator is properly grounded and generator is at a 60Hz frequency.

4. In the event that a generator is being used and the generator runs out of fuel, make sure the heater switch is in the "OFF" position before restarting generator, failure to do so may damage heater.

### **TO SHUT DOWN:**

1. Close main gas supply valve while heater is operating.
2. Move toggle switch to "OFF" position. The main fan will run until the heater exchanger cools down. Do not disconnect power supply until the heat exchanger cools down.
3. Disconnect fuel supply from heater.

**NOTE:** Fan will continue to operate after the burner shuts down. Once the unit cools down, the fan will stop.

### **IF HEATER FAILS TO START:**

1. Press manual reset button at rear of burner.
2. Check gas pressure supply. Supply and manifold pressure must follow those on rating plate.
3. Ensure proper power supply and extension cord is being used.
4. If heater fails to ignite after 3 attempts, call your supplier for service.

### **SAFE OPERATION PRECAUTIONS:**

1. For use with propane or natural gas only. See approval label.
2. Use toggle switch to shut down the heater. Do not try to shut down the heater by unplugging the electrical cord.
3. Do not plug anything other than the thermostat into the "Thermostat" plug.
4. Follow electrical requirements shown on rating plate and/or Electrical requirements section of this manual.
5. Before removing any guards or performing any maintenance, be sure that the main power supply is disconnected.

## COMBUSTION AIR ADJUSTMENTS:

**NOTE:** Proper combustion air adjustment must be achieved using a certified combustion analyzer to ensure complete combustion.

The air adjustment should be made to achieve 10% CO<sub>2</sub> on natural gas and 12% CO<sub>2</sub> on propane.

### SETTING THE AIR ADJUSTMENT PLATE

**A)** Regulation of the combustion air flow is made by adjustment of the manual AIR ADJUSTMENT PLATE (1) after loosening the FIXING SCREWS (2 and 3). The initial setting of the air adjustment plate should be made according to Column 5 in the Burner Set-up Chart.


**B)** The proper number on the manual AIR ADJUSTMENT PLATE (1) should line up with the SETTING INDICATOR (4) on the fan housing cover. Once set, the air adjustment plate should be secured in place by tightening SCREWS 2 and 3.

**C)** The final position of the air adjustment plate will vary on each installation. Use instruments to establish the proper settings for maximum CO<sub>2</sub>.

**NOTE:** Variations in flue gas, CO<sub>2</sub> and temperature readings may be experienced when the burner cover is put in place. Therefore, the burner cover **must** be in place when making the final combustion instrument readings, to ensure proper test results.

### BURNER SET-UP CHART

1	2	3	4
<b>FIRING RATE (BTUH)</b>	<b>ORIFICE-</b>	<b>HEAD SETTING</b>	<b>AIR DAMPER SETTING</b>
200,000 NG 200,000 LP	PART # FVN-226	5	3.5 NG 3.0 LP




## TEMPERATURE FEELER GAUGE ADJUSTMENT (ATTACHED TO FAN SWITCH)

The temperature feeler gauge is required to be always touching the heater exchanger.

The temperature feeler gauge controls the air flow over the fan switch, which eliminates any unnecessary fan cycling. The temperature feeler gauge can be adjusted for different outside temperatures, by rotating the location of the temperature feeler gauge holes. This will provide maximum performance of the unit in different applications.

If supply air is warm ( $-5^{\circ}\text{C}$ , indoor application):


Turn the temperature feeler gauge so that the holes are parallel with the heat exchanger. This will help the fan switch to remain cool and not overheat. See following:



If supply air is cold (under  $-5^{\circ}\text{C}$ ):

Turn the temperature feeler gauge so that the holes are closed off as the air goes over the heat exchanger. This will reduce fan cycling and the unit from shutting down.


See following:




In extreme cold conditions, cover the holes on the temperature feeler gauge using foil tape. Ensure that the temperature feeler gauge is readjusted for warmer weather conditions. Failure to do so may result in burning out fan switches – not covered under warranty.

## PRINCIPAL BURNER COMPONENTS

1. Electric air shutter assy. (Optional)
2. Field wiring terminal Block
3. Capacitor
4. Gas valve Transformer 120V/24 V (Optional)
5. Integrated primary/ Ignition control
6. PSC burner motor
7. Combustion air proving switch



## BURNER DIMENSIONS




Model 200	A	B	C	F	G	*G1	H
Inches	9 3/16	10 11/16	6 11/16	11 5/8	3 15/16	10	3 9/16
mm	233	272	35	295	85	255	91

\*G1 is for LBT version

Gasket thickness is 4 millimeters

## ELECTRODE AND FLAME PROBE ADJUSTMENTS




**IMPORTANT:** Do not turn the ignition electrode. Leave it as shown in the drawing. If the ignition electrode is put near the ionization probe, the amplifier of the control box may be damaged.

## TYPICAL GAS TRAIN LAYOUT

FIELD SUPPLIED

RIELLO SUPPLIED




**NOTE: ITEMS 5,6 & 7 COMBINATION GAS VALVE(S) ASSEMBLIES MAY BE UTILIZED WHERE APPROVED.**

### GAS TRAIN LEGEND

- |  |   |
|--|---|
| <b>1</b> GAS SUPPLY & FLOW DIRECTION OF GAS                    | <b>5</b> GAS APPLIANCE PRESSURE REGULATOR                             |
| <b>2</b> AS SUPPLY MAIN SHUTOFF MANUAL VALVE (FIELD SUPPLIED)  | <b>6</b> SAFETY SHUTOFF GAS VALVE (VS) 24V OR 120V SUPPLIED) OPERATED |
| <b>3</b> GAS SUPPLY PRESSURE TEST POINT (FIELD SUPPLIED)       | <b>7</b> MAIN GAS VALVE (V1) 24V OR 120V OPERATED SINGLE STAGE        |
| <b>4</b> GAS TRAIN PIPE DIAMETER SIZE(S): BURNER G200 1/2" NPT | <b>8</b> GAS BURNER MANIFOLD TEST POINT                               |


## FIELD WIRING DIAGRAM




### LEGEND

L = Line 1 (phase)	Gnd. = Ground
N = Line 2 (Neutral)	V1, V2 = Gas valve terminal
F = Fuse	TT = Thermostat
* 24 V switching relay as approved optional.	

## FACTORY WIRING DIAGRAM



G 200 DUAL FUEL LP/NG BURNER - PARTS DIAGRAM





<u>RIELLO BURNER G200 - PARTS LIST DIAGRAM</u>		
N#	PART NUMBER	DESCRIPTION
1	FV-20136483-LPGN	PLASTIC BURNER COVER C/W LABELS
2	FVNP-3020321	AIR PRESSURE SWITCH
3	FVNP-3002307	SUB-BASE FOR IGNITION MODULE
4	FVNP-300162	IGNITION MODULE
5	FVNP-C7020005	TRANSFORMER
6	FVNP-3007288	AIR SWITCH TUBE & CONNECTOR
7	FVNP-3007310	IONIZATION LEAD
8	FVNP-3007292	AIR TUBE COVER PLATE
9	FVNP-3006687	MOUNTING COLLAR
10	FVNP-3007448	GROUND LEAD & CONNECTOR
11	FVNP-3007204	AIR DAMPER
12	FV-3005708	BURNER FAN
13	FVNP-3005834	BURNER CAPACITOR
14	FVO-C7001034	BURNER MOTOR
16	FVO-3005855	MOUNTING FLANGE
17	FVNP-3020228	DIAPHRAM
18	FVNP-3006695	DRAWER ASSEMBLY ELBOW
19	FVNP-3007274	ELECTRODE ASSEMBLY
20	FVNP-3007265	ELECTRODE & IONIZATION CLAMP
21	FVNP-3020206	FLAME ROD ASSEMBLE
22	FVNP-3007298	MANIFOLD
23	FVNP-3007289	NG TUBE
24	FV-3005854	SEMI-FLANGE
25	FVNP-3006394	FLAME FUNNEL
26	FVNP-3007281	TOOTH
27	FVN-226	MAIN BURNER ORIFICE
28	FVNP-3006899	DISTRIBUTOR HEAD & MIXING PLATE
29	FVNP-3007303	ELECTRODE SUPPORT
30	FVNP-3007284	EXTENSION
31	FVNP-3005447	TEST POINT
32	FVNP-3000870	HINGE ASSEMBLY



26 Benfield Drive , St.Catharines Ontario Canada  
 905-685-4243  
 12949 Eagle Creek Parkway, Savage MN USA  
 866-266-2484

## FVNP-200RC – PARTS LIST



**1/2 HP MOTOR**

**FV-201**



**14" IMPELLER**

**FV-202RC**



**VENTURI FOR 14" BC IMPELLER**

**FV-202RCA**



**12" WHEEL FLAT FREE**

**FV-203A**



**6" LOCKABLE CASTER WHEEL**

**FV-207**



**SS HEAT EXCHANGER**

**FV-205**



**HIGH LIMIT OUTLET (180F)**

**FV-242**

**HIGH LIMIT BURNER (150F)**

**FV-437**



**FAN LIMIT SWITCH**

**FV-407A**



**FAN LIMIT GASKET**

**FV-407G**



**FEELER GAUGE**

**HOLES – FV-433**

**SOLID – FV-433B**



**TOGGLE SWITCH**

**FV-409**



**RED LIGHT**

**FV-411**



**POWER INDICATOR  
LIGHT**

**FV-450SI**



**THERMOSTAT PLUG  
(ON CONTROL BOX)**

**FV-414B**



**POWER CORD**

**FV-204**

## FVNP-200RC – PARTS LIST



**THERMOSTAT PLUG  
(PLUG ON THB)**

**FV-415A**



**CONTROL BOX  
(EMPTY)**

**FV-2P08RC**



**CONTROL LID**

**FV-2P09RC**



**HIGH LIMIT BOX (1 HOLE)  
FV-P11  
HIGH LIMIT BOX (2 HOLES)  
FV-P10**



**LIMIT BOX LID**

**FV-P12**



**WHEEL AXLE**

**FV-240**




**RC HOOD**

**FV-208RC**



**INLET DUCT SCREEN**

**FV-208IR**



**CANOPY INLET RING**

**FV-208IFP**



**MOTOR MOUNT BRACKET**

**FV-2P05RC**



**REAR BURNER MOUNT PANEL**

**FV-2P04RC**



**FRONT FACEPLATE  
FV-234CB12 – 12"  
FV-234CB16 – 16"**



**HEATER FRAME**

**FVNP-2FRC**



**TOP BODY PANEL**

**FV-2P01RC**



**BOTTOM BODY PANEL**

**FV-2P02**

## **FVNP-200RC– PARTS LIST**



**4 WIRE BX CABLE  
HIGH LIMIT BOX TO  
CONTROL BOX  
FV-471**



**2 WIRE BX CABLE  
(HIGH LIMIT BOX TO  
HIGH LIMIT BOX  
FV-472**



**G200 BURNER  
FVNP-224**



**BURNER ORIFICE  
FVN-226**



**BURNER GASKET  
C/W CLAMP  
FV-231**



**FUEL SELECTOR VALVE  
FVNP-231  
½" SHUT OFF VALVE  
2103-D-CGA**



**½" ASCO SOLENOID  
FVNP-C5850608**



**½" MAXITROL REG  
FVNP-C5852000**



**VALVETRAIN BRACKET  
FVNP-230**

# PARTS LIST FOR FVNP-200RC

<b>Part Number</b>	<b>Part Description</b>
FV-201	1/2 HP Fan Motor
FV-202RC	14" BC Impeller
FV-202RCA	Venturi For 14" BC Impeller
FV-203A	12" Wheel FLAT FREE
FV-204	12" Power Cord c/w Plug End
FV-205	SS Heat Exchanger
FV-2P01RC	Top Body Panel
FV-2P02	Bottom Body Panel
FV-P04RC	Rear Burner Mount Panel
FV-P05RC	Motor Mount Bracket
FV-208RC	RC Hood
FV-208IFP	Canopy Inner Faceplate
FV-208IR	Canopy Inlet Ring
FV-2P08RC	Control Box
FV-2P09RC	Control Box Lid
FVNP-2FRC	Frame
FV-P10	Limit box (Double Hole)
FV-P11	Limit box (Single Hole)
FV-P12	Limit Lid
FV-242	High Limit Switch (Outlet) 180F
FV-407A	Fan Limit Switch (Adjustable)
FV-407G	Fan Limit Silicone Gasket
FV-207	6" Lockable Caster Wheel
FV-270	14" BC Impeller Fan Housing (Complete)
FV-271	Inlet Ducting Screen Ring Assembly
FV-409	Toggle Switch (on control box)
FV-411	Red Light (on control box)
FV-414B	Thermostat Plug (on control box)
FV-415A	Male Connector for FV-THB
FVNP-224	Riello G200 Burner (LP/NG)
FVNP-230	Valvetrain Bracket
FVNP-231	Fuel Selector Valve

FVNP-C5850608	1/2" Asco Solenoid Valve FVNP-200RC 2019>
FVNP-C5852000	1/2" Maxitrol Regulator FVNP-200RC 2019>
FV-231	Burner Gasket
FV-433	Feeler Gauge
FV-433B	Feeler Gauge-Solid
FV-234CB12	Front Face Plate (1 x 12")
FV-234CB16	Front Face Plate (1 x 16")
FV-437	High Limit (Rear) 150F
FV-240	Wheel Axle FV-200 Series
FV-446	Sight Glass c/w Fiber Gasket
FV-447	Sight Glass Washer
FV-450SI	Power Indicator Light
FV-471	4 Wire BX Cable (High limit box to Control Box)
FV-472	2 Wire BX Cable ( High limit box to High limit Box)
2103-D-CGA	Fuel Shut-off Valve

	<b>ACCESSORIES</b>
FV-HD12	12" X 12ft Ducting - Pin Lock ( Used for inlet and outlet)
FV-HD12X25	12" X 25ft Ducting - Pin Lock
FV-HDG16	16" x 25ft Ducting - Cuff & Buckle
FV-THB	Thermostat c/w 25 FT Cord
FV-THB (15M)	Thermostat c/w 50 FT Cord
FV-VK	6" x 3FT C-Vent c/w Rain Cap

# FV-200RC SERIES - WIRING SCHEMATIC 2018

